


RS 232

ROLEC

/Cannon 9 F/

/Cannon 25 F/



PC
/Cannon 9 F/

3U
/Cannon 25 M/

RxD (2) ■

■ (2) TxD

TxD (3) ■

■ (3) RxD

GND (5) ■

■ (7) GND

RTS (7) ■

■ (4) RTS

CTS (8) ■

■ (5) CTS

PROPAC

/Cannon 9 F/

■ (2) RxD

■ (3) TxD

■ (5) GND

■ (1) RTS

■ (4) CTS

Schemat połączeń kabla komunikacyjnego dla RNT serii 6/6E